

Spring USA®
The Evolution of Intelligent Design®

Cereal Dispensers

Single, Double & Triple Units



To Use:

With the vessel placed inside of the stand, remove the cover from the polycarbonate vessel. Fill with contents and replace cover.

Care & Maintenance:

Clean your Cereal Dispenser with mild detergent, and rinse thoroughly with warm water.

Remove cover. Gently remove the cylinder from the base by firmly holding the base, and twisting the cylinder out of the stand.

Run warm water through the acrylic vessel, remembering to turn the wheel of the dispenser, so that each blade gets rinsed.

Wipe down the interior and exterior surfaces of the Dispenser & Base with a clean, soft cloth.

Do Not:

Do not use abrasive pads or scouring powders to scrub any of the parts or surfaces of the Cereal Dispenser.

Do not use paper towels to dry any part of the Cereal Dispenser.

Do not put the polycarbonate vessel or the base of the of the Cereal Dispenser in the dishwasher.

Do not immerse any part of the Cereal Dispenser or the base of the Cereal Dispenser into very hot water.

Single Dispenser 2531



Double Dispenser 2531-2



Triple Dispenser
2531-3



*Each Cylinder has a
10-Liter Capacity!*

**Triple Dispenser features
a Convenient, Rotating
Base for Easy Dispensing**



Spring[®]
USA

The Evolution of Intelligent Design[®]