



Use & Care of Your Spring USA Beverage Servers (Series 175, 176, 185, 186, 195 & 196 Servers)

***** Do Not Disassemble For Cleaning *****

Clean your beverage server with mild detergent and rinse with warm water. Dry the outside of the server body with a soft cloth to avoid scratching the finish. Invert the server in a draining rack or dish rack to allow the inside of the server body to dry.

Do not allow your beverage server to remain submerged in water for a long period of time.

Do not use a wire brush or metal utensil for cleaning your server. Over time, you could damage the interior finish of the server. We recommend an all-plastic (nylon) bottle brush to clean the inside liner of your carafe.

Your beverage server can be placed in the dish machine, but hand washing is the preferred method for cleaning. Harsh chemicals, used in a dish machine, could damage your server.

Under no circumstances, should the handle and spout be disassembled from the vessel.

Replacement tops can also be ordered for the Sigma and Omega beverage servers (only). Locate the Item # on the bottom side of your server – contact our office and request to speak to one of our Sales Coordinators to order your replacement tops.

