

Use & Care Instructions

Cereal Dispenser

Coffee Urn

Juice Dispenser

Milk Dispenser



Spring USA

800-535-8974

www.springusa.com



Juice & Cereal Dispensers

Directions for Use/Cleaning:

Clean the Juice/Cereal Dispenser with mild detergent, and rinse thoroughly with warm water. Run warm water through the faucet of the dispenser.

Dry the unit using a clean, soft cloth.

Do Not:

Do not use abrasive pads or scouring powders to scrub any of the parts or surfaces of the Juice/Cereal Dispenser.

Do not put the polycarbonate vessel of the Juice/Cereal Dispenser in the dishwasher.

Do not immerse the polycarbonate vessel of the Juice/Cereal Dispenser into very hot water.

Do not use the Juice Dispenser for hot beverages.

Do not carry a filled Juice Dispenser by the faucet ~ the stress will fracture the plastic.

To Use:

Fill the ice tube with ice to cool the content (Juice Dispenser only).

Pour the juice into the container (Juice Dispenser only).

Coffee Urns & Milk Dispensers

Directions for Use/Cleaning:

Clean the Coffee Urn or Milk Dispenser with mild detergent, and rinse thoroughly with warm water. Run water through the faucet of the dispenser as well.

Dry the unit using a clean, soft cloth.

Do Not:

Do not use abrasive pads or scouring powders to scrub any of the parts or surfaces of the Coffee Urn or Milk Dispenser.

To Use:

Fill the urn with a hot beverage (Coffee Urn only). Heat using canned fuel or Electric Heating Element.

Fill the ice tube with ice to cool the content (Milk Dispenser only).

Pour milk into the container (Milk Dispenser only).